

Pay timer codes are e-mailed to the dealer via e-mail upon Milltronics' receipt of payment. The particular person who receives this varies by organization. A form is sent along with the sales order confirmation requesting a designated recipient of this code.

Changing of the compact flash card requires a new pay code be issued. The card must be reinstalled before the code can be generated. Replacing a motherboard may also require resetting a pay code, however this repair is seldom done in the field.

To get a pay code:

1. Get the 8 digit Control Identifier (or Identifier) from the **F10 Utilities – F8 Info** page.
2. Get the 8 digit Servo Revision from the **F10 Utilities – F8 Info – F9 Misc** page.
3. E-mail those two numbers and the machine serial number to paytimer@milltronics.net to receive the new pay code.

Enter the new pay code under **F10 Utilities – F10 Gokey – F1 Code**.

The code will come in two parts of 8 digits each. Part B of a permanent code will all be the same character.